




BLINKENBIKE®

GO Your Own Way



Brugermanual - Owners manual

Model: WildDuck

CE Approved

DANSK

Tillykke med din nye **BLINKENBIKE®** – løbecyklen som tilføjer dit barns cykeltræning en helt ny dimension. **BLINKENBIKE®** konceptet er designet til at pirre børns nysgerrighed ved at integrere leg og læring. Bare ved at præsentere dit barn for **BLINKENBIKE®**, og straks er barnet i gang med at udforske og afprøve de mange muligheder. Med en **BLINKENBIKE®** vil dit barn ikke alene lære at cykle meget tidligere, dit barn vil helt naturligt blive motiveret til at træne sine motoriske evner.

Vi vil gerne takke dig for at du valgte vores produkt, og håber at dit barn får en masse dejlige stunder. Vi håber også at I har lyst til at holde kontakten med os på de sociale medier og på vores hjemmeside, hvor I kan tilmelde jer vores nyhedsbrev.

Vi vil elske at se billeder og tegninger af jeres barns **BLINKENBIKE®**, som I kan uploade på vores hjemmeside - www.blinkenbike.dk - hvor I også kan finde nye gratis downloads.

PASSEND E ALDER OG VÆGT

Børn fra 18 mdr.

Maksimal vægt: 23 kg

ADVARSEL!



Undgå skader og ulykker. Det er vigtigt at overvåge barnets leg og undgå brug i nærheden af trapper, indkørsler, biler og andre motoriserede køretøjer, svømmebassiner, på offentlig vej og cykelsti. Sørg for at barnet er iført robuste sko, evt. handsker og en godkendt velsiddende cykelhjelm. Løbecyklen bør aldrig benyttes af mere end ét barn ad gangen, og vær opmærksom på at dit barn kan miste evnen til at styre løbecyklen når han/hun er træt eller udmattet.

SMÅ DELE (før samling)



Dette er en delvist samlet løbecykel, som skal færdigsamles af en voksen i henhold til denne manual. Vær sikker på at alle dele er spændt tilstrækkeligt uden at overspænde, og husk at efterspænde med jævne mellemrum.

Den usamlede **BLINKENBIKE®** indeholder små dele som udgør kvælningssrisiko for små børn. Hold disse dele væk fra barnet indtil løbecyklen er færdigsamlet. Når løbecyklen er samlet indeholder den kun dele som er nøje udviklet til ikke at udgøre en kvælningssrisiko. Instilling af sadlen bør dog kun foregå under voksen supervision.

OPBEVARING OG VEDLIGEHOLD

Opbevar altid din **BLINKENBIKE®** indendørs om natten hvor den er varm og tør.

Rengør med en fugtig klud og vedligehold med en passende voks eller lignende til træbehandling for at bevare træets/malingen udtryk/finish.

Giv hjullejerne lidt let cykelolie, hvis de begynder at løbe trægt.

NB! Opbevar venligst denne brugermanual sammen med din kvittering og navn på producent og forhandler.

BLINKENBIKE® er et registreret varemærke tilhørende Blinkenbike ApS.

ENGLISH

Congratulations with your **BLINKENBIKE®** – the concept that takes the balance bike to a higher level of learning. The **BLINKENBIKE®** Concept is designed to inspire kid's curiosity by integrating playing and learning. Let your kid start out with exploring and designing his/her own riding toy and see how curiosity rises. With the **BLINKENBIKE®**, your kid will not only develop his/her motoric skills, he/she will also get acquainted with the joy and freedom of riding on two wheels earlier than you ever thought possible. We would like to thank you for your purchase and wish you and your child the best. We encourage you to stay connected with us on social medias and on our homepage, where you can sign up to our newsletter.

We would love to see photos and drawings of your kids **BLINKENBIKE®**. - upload them on our homepage - www.blinkenbike.dk - where you can also find new free templates for download.

APPROPRIATE AGE AND WEIGHT

Kids from 18 Months

Maximum Rider weight: 50 POUNDS / 23 KG

WARNING!



To avoid serious injury: Continuous adult supervision is required; never use near steps, sloped driveways, motor vehicles, hills, alleys, swimming pool areas, public roads; always wear sturdy shoes and properly adjusted helmet. Gloves are also a good idea while using the riding toy. Never allow more than one rider on the toy. Riding is hard work and children should be physically able to control the bike. Pay attention to if your child shows any signs of fatigue.

SMALL PARTS (before assembly)



This is a partially assembled riding toy requiring assembly by an adult according to this manual. Be sure to tighten all parts carefully without over tightening, and remember to retighten from time to time.

The un-assembled **BLINKENBIKE®** contain small parts that are a choking hazard to young children - please take care to keep these small parts away from young children. After assembly, the **BLINKENBIKE®** only contains parts that are carefully designed to avoid choking hazards. Adjustment of saddle height should only be done under adult supervision.



STORAGE AND MAINTENANCE

Always store your **BLINKENBIKE®** indoors overnight where it is warm and dry.

Maintain your wooden toy's appearance by cleaning with a damp cloth and using a wood wax or polish to maintain the wood/paint finish. If the wheels are not moving smoothly, lubricate them lightly with a standard bicycle oil.


NOTICE: Please retain this owner's manual for future reference including the name and address of the importer/manufacturer.

BLINKENBIKE® is a registered trademark of Blinkenbike ApS.




A

x2





B

12"x1.75"





12"x2.25"

C



D





BLINKENBIKE®

Creative Designer

